

BROTHER HL-L2370DW – Turn Off DEEP SLEEP

Summary

Deep Sleep mode on the Brother HL-L2370dw printers needs to be turned off. Deep Sleep mode will cause the printer not to print. For some reason the Chromebook (CB) will not "wake" the printer from Deep Sleep mode.

To disable Deep Sleep mode by using the LCD display on the printer follow the steps below:

1.	With the LCD panel showing Ready press the Down Arrow 1x to General Setup
2.	Press OK
3.	Press the Down Arrow 3x to Ecology
4.	Press OK
5.	Press the Down Arrow 2x to Sleep Time
6.	Press O
7.	Press the Down Arrow 1x and set the Sleep Time to 50
8.	Press the Down Arrow and Back Key <u>simultaneously</u> and you will see Deep Sleep
9.	Press OK and you will see ON
10.	Press the Down Arrow 1x and you will see Off
11.	Press OK and you will see Accepted
12.	Press the Back Button 4x to return to the Ready status