

Quick Startup to Standard Configuration

Summary

This is a condensed startup procedure to re-configure the standard AARP Brother HL-L2370dw printer from a Factory default reset to connect wired or wirelessly to a standard AARP router. For first time users and those using non-standard settings, please refer to the rest of the document.

A. Reset to factory default then re-configure to standard setting

1.	Control panel > Initial Setup > Reset > Factory Reset
2.	Connect the printer to the AARP router using an ethernet cable
3.	Print the network configuration report: Control Panel > Print Reports > Network Configuration
4.	Read the dynamic IP address and the default password from the report
5.	Open Chrome, enter Printer IP address to open the admin page and login using default password
6.	General Tab: Set Sleep time to 50 min. , Set Auto Power off to 8 hours , set Panel contrast to +2 , Set Replace Toner to Continue. > Submit
7.	Print Tab > Print: Toner Save > Submit, 2-sided - Long Edge > Submit
8.	Administrator tab > Login Password , change the factory default password to your local standard password. Submit.
9.	Network tab > Network > Interface: Set Auto-Switching ON, Set Wi-Fi Direct OFF > Submit
10.	Network tab > Network > Protocol: Set AirPrint, Mobile Printing for Windows and mDNS to OFF > Submit

B. Set static IP address for wired mode

11.	Network tab > Wired > TCP/IP: IP Address: 192.168.234.50, Subnet mask: 255.255.255.0, set Gateway: 192.168.234.1, Boot Method: Static, APIPA ON > Submit , printer reboots.
12.	Enter new IP address 192.168.234.50 in the Chrome address bar and login again

C. Set static IP address for wireless mode and select network

13.	Network tab > Wireless > TCP/IP: IP Address = 192.168.234.50, Subnet mask = 255.255.255.0, Gateway = 192.168.234.1, Boot Method: Static, APIPA ON > Submit
14.	Network tab > Wireless > Wireless (Personal): Wireless Network Name (SSID) > Browse > Select the AARP network, Authentication Method: WPA/WPA2-PSK, Encryption Mode: AES, Passphrase (= your Network password) > Submit
15.	Remove the ethernet cable, check WiFi LED is steady green

D. Update Firmware

16.	Administrator tab > Firmware update > Check for New Firmware
-----	---

E. Test Printer

17.	On any Chrome tab, click " Ctrl-P " to open the print dialog
18.	Select the managed printer " Tax-Aide Brother HL-L2370DW " (if you don't see it, open drop down list > See More)
19.	Print

For further information see document [P02 Brother HL-L2370dw Network Printer Setup Guide for Chromebooks](#)

Revised 9/21/2024